


PowerBox Systems[®]


*World Leaders in RC
Power Supply Systems*

ECU Update Manual




Open the ECU Motor Control and click on **UPDATE**.


ATTENTION: Ensure a safe powersupply. A power loss during update may cause a crashed software copy.




This window will open – click **OK**



On your desktop you will find the **PowerBox Terminal** button. Click it



This window will open, click on **Continue**:




The Terminal program will find the **ECU**.




Now you have 2 options: Online update or Select file. To use the online update your computer must have an internet connection. Select file can be selected also on the field when the *.pbs file is on the machine.


Select file, you will get this window. Select the **ECU_Typ_A.pbs** file



You will get this window:



Click **Continue**, after some seconds the software update has finished, and you will see this screen.



PowerBox-Systems GmbH
certificated according to DIN EN ISO 9001:2008
Ludwig-Auer-Straße 5
D-86609 Donauwörth
Germany

Tel: +49-906-22 55 9
Fax: +49-906-22 45 9
info@PowerBox-Systems.com

www.PowerBox-Systems.com